

1/8




FIG. 1




FIG. 4




FIG. 2




FIG. 3




FIG. 5

T001234567890




FIG. 6




FIG. 7




FIG. 8

099115685 • 072400

8/8

Set rpm		Activate Gear/Synchronization/Gearing On		Stop Axis/ Stop Motion Is a Command		Macro	
Set Torque		Turn Off Synchronization		Stop Command		Call Up Subprogram	
Start Axis Position Controlled		Activate Cam Plate/Camming		Continue Motion			
Position Axis		Turn Cam Plate Off					
		Parameterize Cam Plate					

FIG. 9